Construction & Demolition Site Stormwater Compliance Presentation for CALBIG October 12, 2022

Peter Schultze-Allen, CPSWQ, QSD/QSP Senior Scientist, EOA, Inc. on behalf of SMCWPPP (the San Mateo Countywide Water Pollution Prevention Program)



Outline of Presentation

- What is SMCWPPP?
- Why are stormwater regulations important?
- Overview of stormwater regulations
- Construction site inspection requirements
- Stormwater inspection documentation & tracking
- Construction site best management practices
- Resources




Overview of SMCWPPP

San Mateo Countywide Water Pollution Prevention Program (SMCWPPP):

- Program of City/County Association of Governments of San Mateo County (C/CAG)
- 20 Cities & Towns plus County and One Shoreline (aka "SMC Flood and Sea Level Rise Resiliency District")
- Assist Municipalities with Countywide Stormwater Permit Compliance Activities
- Reid Bogert, Senior Program Specialist
- Website <u>www.flowstobay.org</u>



SMCWPPP Organizational Structure





Why are Stormwater Regulations Important?

California Regional Water Quality Control Board San Francisco Bay Region Municipal Regional Stormwater NPDES Permit

> Order No. R2-2022-0018 NPDES Permit No. CAS612008 May 11, 2022





Pollutants in the Bay Impact Human Health

- San Francisco Bay is impaired by pollutants in fish.
- Concentrations increase as you move up the food chain
- Exposure results in cancer risk and other health concerns







Stormwater – What's the Big Deal?

- Rain washes pollutants away
- Flows into inlets and underground pipes
- Discharge directly to creeks, the Bay, or the Pacific Ocean
- No treatment to remove any pollutants
- Impacts water quality and aquatic life



What Pollutants?

- Sediment
- PCBs
- Mercury
- Pesticides
- Trash/Litter
- Nutrients/Fertilizers
- Construction Materials
- Vehicle-Related
 - Metals, oil/hydrocarbons, washwater
- Bacteria
 - Pet waste, livestock, sewer, etc.





Many Bay Fish Are Not Safe to Eat



 Fish consumption advisories led to the development of a pollution "diet" for PCBs and Mercury known as a Total Maximum Daily Load or TMDL




Stormwater Regulations



Water Pollution

Municipal Regional Permit (MRP)

- Regional permit regulating municipal stormwater systems
 - Requires a Construction Site Control Program
- 1st MRP adopted in December 2009
- 2nd MRP adopted in November 2015
- 3rd MRP adopted in May 2022
 - Took effect on July 1, 2022
 - However, most new and redevelopment related requirements are not taking effect until July 1, 2023.







San Mateo County Applicable MRP Provisions

Topic S	Specific	Pollutant	Specific	Monitoring/Reporting				
C.2 Municipal Operations	C.6 Construction Site Controls	C.9 Pesticides Toxicity Control	C.13 Copper Controls	C.8 Water Quality Monitoring	C.16 Discharges to ASBS			
C.3 New Development and Redevelopment	C.7 Public Information and Outreach	C.10 Trash Load Reduction	C.14 Bacteria Controls	C.20 Cost Reporting	C.21 Asset Management			
C.4 Industrial/ Commercial Site Controls	C.15 Exempted and Conditionally Exempted Discharges	C.11/12 PCB and Mercury Controls	C.18 Control of Sediment Discharges from Coastal SMC					
C.5 Illicit Discharge Controls	C.17 Unsheltered Homeless Populations							



What is Green Infrastructure?

- Systems (stormwater control measures or SCMs) that use vegetation, soils, and natural processes to capture and treat stormwater in urban environments
- Most municipal GI projects will involve <u>retrofitting</u> existing public streets, roofs, and parking lots to divert stormwater runoff to:
 - Vegetated areas
 - Pervious pavement
 - Biotreatment and infiltration facilities




Permit Requirements for GI


- Implement long-term GI Plan
- Conduct education and outreach
- New! Install GI in "regulated projects" categories including certain:
 - Road reconstruction projects
 - Road maintenance projects
 - Frontages of parcel-based regulated projects
- Install GI in projects where feasible "no missed opportunities"
- Opportunity projects may include buildings, parking lots, parks and streets



Missed C.3 GI Opportunity




GI Installed





GI Installed





Public GI Retrofit Opportunity





Public GI Installed





Statewide Construction Activities General Permit

ain	ı E	vent Action Plan	(]	REAP)
		WDID Number:		
		Predicted % chance	ofra	in:
				I
matio		Project Risk Level: 🗆 Risk Lev	el 2	Risk Level 3
made	<i>и</i> .			
Numb				
Contr	acto	4/// r – Labor Force contracted for th	e si	te:
iber (2	4/7)			
nber (2.	4/7)	Current Phase of Construction		
Che	ck Al	LL the boxes below that apply to your :	site.	
ment	_	Vertical Construction		Inactive Site
		Final Landscaping and Site Stabilization		Other:
		ctivities Associated with Current		
the bo at:	xes b	elow that apply to your site (some app	ply to	o all Phases).
		Vegetation Removal		Vegetation Salvage-Harvest
		Finish Grade		Blasting
		Excavation (ft)		Soils Testing
		Erosion and Sediment Control		Surveying
ng		Material Delivery and Storage		Other:
-				
		Utility Install: water-sewer-gas		Paving Operations
ng		Storm Drain Installation		Material Delivery & Storage
Pour		Masonry		Other:
		Carpentry		Concrete/Forms/Foundation
		Electrical	- -	Painting
	ā	Plumbing	ā	Stucco
ng		HVAC		Tile
		Insulation		Landscaping & Irrigation
		Roofing		Other:
lizati	on:	Vegetation Establishment		E&S Control BMP Removal
		Storage Yard/ Material		Landscape Installation
	_	Removal	_	-
		Irrigation System Testing		Other:
	•	Inlet Filtration		Perm. Water Quality Ponds
		Other:		Other:
n ace	2	Routine Site Inspection	8	Trash Removal Other:
ace		Street Sweeping	ч	Other:

 Compliance inspections/enforcement by State or Regional Water Board staff

- The reissued CGP was approved on September 8, 2022 and will take effect on September 1, 2023.
- Significant new requirements/changes including:
 - Admin (e.g., NOT), BMPs, TMDLs, monitoring, and QSD/QSP responsibilities. More details at the 2023 CALBIG training.
- Contains requirements for site:
 - BMPs, Inspections, Sampling
 - SWPPP, Reporting, QSP/QSD



What Do You Need to Know About the Construction General Permit (CGP)?

- Speaking with the QSP and reviewing SWPPP, inspection records, and sampling results, etc. may help inform your MRP inspection
- Public projects ≥ 1 acre must file for coverage under the CGP - will you be involved?
- Overall site compliance reflects on your inspection program
 - You inspect for compliance with local SW ordinance
 - Regional Board staff inspects for compliance with CGP



MRP Requirements for Construction Sites



MRP-required SW Inspections

- Construction Site Stormwater Inspections (C.6)
 - <u>During</u> all phases of <u>construction</u>
 - Inspect temporary BMPs
- Stormwater Control Measures (SCM) Inspections (C.3)
 - **Recommended** <u>during</u> construction
 - Required at completion of construction
 - Inspect these <u>permanent</u> control measures for on-going operation and maintenance SW treatment or hydromodification controls
- SW Inspections can be on public or private property or in the street (C.3-GI)

Construction Site Inspection Requirements

Big Picture Requirements...

- Implement a construction site inspection and control program <u>at all construction sites</u>
- Prevent discharges of pollutants and impacts on receiving waters
- When does this apply?

-<u>All year long!</u>



- During the wet season, the following sites must have stormwater inspections at least once per month:
 - Sites disturbing > 1 acre
 - Hillside Sites of <u>> 5</u>,000 sq.
 - High priority sites







- Sites disturbing 1 acre or more:
 - Must have monthly rainy season inspections from local agency staff (required by the MRP)

AND

- Need coverage under the State Construction General Permit.
- The site (construction contractor) staff will do self inspections and report them through the SMARTS database.



- What is a hillside site?
 - Disturbs \geq 5,000 sf

AND

- Is on a hillside as defined by:
 - —an average slope of ≥15% (default) or
 - —the Municipality using development maps or criteria (Hillsborough, Pacifica, Redwood City, San Carlos, SSF, Woodside, County)



- What is a high priority site?
 - Identified by your municipality
 - Generally, site with < 1 acre of land disturbance that
 - -Has high potential for problems
 - -Is adjacent to a creek





MRP Construction Site Inspection Requirements

When is the wet season? October 1st – April 30th






When construction ends during wet season:

- Continue stormwater inspections until site is fully stabilized.
- If stabilizing with vegetation, assume "fully stabilized" when there is 70% vegetative cover.
- Note "last" inspection on form and in tracking system
- Verify ALL temporary BMPs are removed (e.g. storm drain inlet protection that may be down the street, straw wattles on vegetated slopes)

 For every required stormwater inspection, there must be a completed inspection report form.





- For sites that require monthly wet season inspections, data from the stormwater inspection form must be:
 - Tracked (in spreadsheet or database), and
 - Reported (in Annual Report)





- Tracking table is not submitted in Annual Report but is the basis for Annual Report data summaries
- Regional Board can request tracking table at any time
- Inspection tables should match summaries in Annual Report

tion	site	ANSWER (ente	ONCE P or 1 for "Y					Problems Observed (Ref 9-15)						
Enter 1 per inspection	Enter 1 for each site	<u>Disturbs ≥ 1 acre?</u> (Ref 6)	<u>Hillside Site?</u> (Ref 7a)	<u>High Priority Site?</u> (Ref 7)	Site Name (Ref 2) ¹	Inspectn Date (Ref 1)	Weather During Inspectn (Ref 1a)	Erosion Control	Sediment Control	Run-on & Runoff	Active Treatmt	Site Management	Non Stormwtr Mgt	Illicit Discharge
1	1				EXAMPLE: Nirvana Estates	EXAMPLE: 12/12/09	EXAMPLE: Light Rain	1	1	1	1	1	1	1



Terminology

Tracking:

- Actual discharges or "illicit discharges"
 - actual and inferred
- Potential discharges or "problems with BMPs"





Inspection Forms



Stormwater Inspection Forms

FAILURE TO CORRECT VIOLATION(S) within 10 business days (or as specified in this notice) may result in PENALTIES described on page 2!

SAN MATED COUNTYWIDE Water Pollution Provention Program 1. Inspection Date:	1a. Current weather conditions:	SPECTION REPORT
2. Name of Project:	2	2a. Project No./Permit No
3. Project Address:		
4. Inspection Type: C Routine C Building Permit	Follow-up Cher Grading Permit Site Devel	lopment CIP Project
6 Project disturb ≥ 1 acre?: Y/N - If Ye Project covered under statewide Constru		NOI Required:(Y/N) SWPPP dated/_/
7. High Priority Site significant threat to wa	ter quality) 7.a Hillside Site?	(Y/N - If Yes, inspect monthly during wet season.)
8. Project Type: Residential	Commerciai/industrial	Institutional Landscaping
Utility (water, sewer	, PG&E) 🛛 Grading 🖵 Demolitio	on Street Improvement Other:
	Inspection Finding	
9. Erosion Control Measures:	(A / NM / P / NA)*	Location on site/Comments
Jute Netting/Fiber Blankets		



Stormwater Inspection Form

- Document Problems in 6 BMP categories:
 - Erosion control
 - Run-on and run-off control
 - Sediment control
 - Active treatment systems (as needed)
 - Good site management
 - Non-stormwater management
- If using the SMCWPPP form you will report findings of:
 - Adequate
 - Needs Maintenance
 - Problems
 - Not Applicable



Erosion & Sediment Control

- Erosion control
 - First line of defense
 - Prevent soil movement by wind and water
 - Examples: soil covers & barriers (slow the flow)
- Sediment control
 - Second line of defense
 - Remove soil before it leaves the site
 - Examples: barriers and filters
- Temporary or Permanent Controls
- Remove temporary BMPs at completion of project



Erosion Control

٥	Erosion Control Measures:	Inspection Finding (A / NM / P / NA)*	Location on site/Comments
5.	Jute Netting/Fiber Blankets	<u></u>	<u>Location on siteroonments</u>
	Mulch		
	Hydroseed/Soil binder/Compost blanket		
	Mark Areas to be Preserved		
	Tree Protection Fencing		
	Riparian Area Barrier		



Examples of Bonded Fiber Matrix (BFM) and netting applications.



Erosion Control Applications

Fiber Rolls and BFM (photos courtesy of Caltrans)



Erosion Control Performance Comparisons BFM with and without a compost blanket



Erosion Control Performance Comparisons Compost berm, seed and irrigation vs. BFM and Fiber Rolls




Erosion Control Applications Compost Blanket, Hydroseed, Coir Netting



Erosion Control Applications

Compost Blanket, Hydroseed, Coir Netting



Six Months Later

Sediment Control

10.	Sediment Control Measures	
	Stabilized construction entrance	
	Street Sweeping	
	Dust Control	
	Wattles / Fiber Rolls / Compost Socks	
	Silt Fences / Compost Berms	
	Sedimentation Basin	
	Check Dams	
	Inlet Filters (Gravel bags)	
	Earth Dikes / Drainage Swales	





Sediment Control Applications Linear Barriers – Compost Berms



Photos courtesy of Caltrans

Sediment Control Applications


Linear Barriers – Compost Berms



Photos courtesy of Caltrans

Sediment Control Applications

Linear Barriers – Compost Socks



Photos courtesy of Caltrans









Inlet Protection with Compost Sock



Inlet Protection with Compost Sock





- Compost socks are good in urban area protecting for stockpiles.
- Compost and mulch that your agency purchases, or where the purchase is required in a contract, can count towards SB 1383 procurement requirements.
- Talk with your solid waste staff.



- Socks can be filled with mulch or compost.
- Inspect a sample of the materials inside socks for trash contamination.

What Else Should You Know About the MRP?

- Provision C.13.a. manage waste generated from cleaning/treating copper architectural features during construction
- SMCWPPP BMP Fact Sheet







Requirements for Architectural Copper

Protect water quality during installation, cleaning, treating, and washing!

Copper from Buildings May Harm Aquatic Life

Copper can harm aquatic life in San Francisco Bay. Water that comes into contact with architectural copper may contribute to impacts, especially during installation, cleaning, treating, or washing. Patination solutions that are used to obtain the desired shade of green or brown typically contain acids. After treatment, when the copper is rinsed to remove these acids, the rinse water is a source of pollutants. Municipalities prohibit discharges to the storm drain of water used in the installation, cleaning, treating and washing of architectural copper.



Building with copper flashing, gutter and drainpipe.

Use Best Management Practices (BMPs)

The following Best Management Practices (BMPs) must be implemented to prevent prohibited discharges to storm drains.

During Installation

- · If possible, purchase copper materials that have been pre-patinated at the factory.
- If patination is done on-site, implement one or more of the following BMPs:
 - Discharge the rinse water to landscaping. Ensure that the rinse water does not flow to the street or storm drain. Block off storm drain inlet if needed.
 - Collect rinse water in a tank and pump to the sanitary sewer. Contact your local sanitary sewer agency before discharging to the sanitary sewer.
 - Collect the rinse water in a tank and haul off-site for proper disposal.
- Consider coating the copper materials with an impervious coating that prevents further corrosion and runoff. This will also maintain the desired color for a longer time, requiring less maintenance.
 Storm drain inlet is blocked to prevent prohibited discharge. The water must be pumped and disposed of properly.

During Maintenance

Implement the following BMPs during routine maintenance activities, such as power washing the roof, re-patination or re-application of impervious coating:

- · Block storm drain inlets as needed to prevent runoff from entering storm drains.
- Discharge the wash water to landscaping or to the sanitary sewer (with permission from the local sanitary sewer agency). If this is not an option, haul the wash water off-site for proper disposal.

Protect the Bay/Ocean and yourself!

If you are responsible for a discharge to the storm drain of nonstormwater generated by installing, cleaning, treating or washing copper architectural features, you are in violation of the municipal stormwater ordinance and may be subject to a fine.



Photo credit: Don Edwards National Wildlife Sanctuar


Contact Information

The San Mateo Countywide Water Pollution Prevention Program lists municipal stormwater contacts at www.flowstobay.org (click on "Business", then "New Development", then "local permitting agency").

FINAL February 29, 2012




PCBs Were Manufactured from 1929 to 1979



MRP 2.0 Provision C.12.g: Manage PCBscontaining Building Materials During Demolition

California Regional Water Quality Control Board San Francisco Bay Region Municipal Regional Stormwater NPDES Permit

> Order No. R2-2015-0049 NPDES Permit No. CAS612008 November 19, 2015



- Review permits for applicable buildings prior to demolition
 - Constructed/remodeled from 1/1/1950 to 12/31/1980
 - Does not apply to wood frame or single-family buildings, or partial building demolitions.
- Manage PCBs-containing materials during demolition:
 - Ensure PCBs are not discharged to storm drains
 - Provide for the necessary authority
 - Test building materials for PCBs and remediate per state/federal law.

MRP 3.0 Provision C.12.g New Requirements

California Regional Water Quality Control Board San Francisco Bay Region Municipal Regional Stormwater NPDES Permit

> Order No. R2-2022-0018 NPDES Permit No. CAS612008 May 11, 2022



- New Requirements!
 - Starting 7/1/23, implement construction (demolition) site control program enhancements
 - Starting 7/1/23, require demolition contractors to provide notification at least one week before demolition occurs
 - Starting 7/1/23, obtain documentation to verify BMPs and proper disposal
 - BAMSC regional project underway to update Applicant Package and provide updated guidance.

Resources



Resources...

- BASMAA PCBs and Demolition Program
 - http://basmaa.org/Announcements/date/27-8-2018
- Caltrans Erosion Control Toolbox
 - <u>https://dot.ca.gov/programs/design/lap-erosion-control-</u> <u>design/tool-1-lap-erosion-control-toolbox</u>
- SMCWPPP Construction BMP Resources
 - http://www.flowstobay.org/construction
- CASQA Construction BMP Handbook Portal
 - Available on web by subscription
 - Contact your municipal stormwater coordinator for information on how to access the portal
 - www.casqa.org



SMCWPPP Website

- www.flowstobay.org
- Hover over "Preventing Stormwater Pollution". Select "Construction Best Practices" in the pull-down menu under "With New and Redevelopment". Scroll to the bottom of the page for brochures.
- Hover over "Data and Resources". Select "Presentations & Workshops" in the pull-down menu under "Resources".
- Hover over "Permittees", select "New Development" committee and log in.





ABOUT FLOWS TO BAY PREVENTING STORMWATER POLLUTION DATA & RESOURCES GET INVOLVED PERMITTEES

The Program operates by appointment only. Click here to learn more.


Additional Resources

- Architectural Copper Requirements
- Best Management Practices to Prevent Stormwater Pollution from Construction-Related Activities
- Building Demolition and Mercury Hazards
- C.6 Construction Site Inspection Report in PDF Form version
- Concrete & Mortar Application
- Construction BMP Plan Sheet: PDF | CAD (will auto download)
- Creek & Wetland Permitting
- Earth-Moving and Dewatering Activities
- General Construction and Site Supervision
- Heavy Equipment Operation
- Landscaping, Gardening, and Pool Maintenance
- Painting and Application of Solvents and Adhesives
- Riparian Erosion and Sediment Control
- Roadwork and Paving
- Stormwater & Construction Poster: Front | Back

CASQA BMP Fact Sheets

Soil Binders





Cat	Categories			
EC	Erosion Control	V		
SE	Sediment Control			
TC	Tracking Control			
WE	Wind Erosion Control	X		
NS	Non-Stormwater Management Control			
WM	Waste Management and Materials Pollution Control			
Lege	end:			
M I	Primary Category			

Secondary Category

Description and Purpose

Soil binding consists of application and maintenance of a soil stabilizer to exposed soil surfaces. Soil binders are materials applied to the soil surface to temporarily prevent water and wind induced erosion of exposed soils on construction sites.

Suitable Applications

Soil binders are typically applied to disturbed areas requiring temporary protection. Because soil binders, when used as a stand-alone practice, can often be incorporated into the soil, they are a good alternative to mulches in areas where grading activities will soon resume. Soil binders are commonly used in the following areas:

- Rough graded soils that will be inactive for a short period of time
- Soil stockpiles
- Temporary haul roads prior to placement of crushed rock
- Compacted soil road base
- Construction staging, materials storage, and layout areas

Limitations

Soil binders are temporary in nature and may need reapplication.

CASQA

1 of 8



California Stormwater BMP Handbook Construction www.casqa.org

Targeted	Constituents
----------	--------------

Sediment	
Nutrients	
Trash	
Metals	
Bacteria	
Oil and Grease	
Organics	

Potential Alternatives

EC-3 Hydraulic Mulch EC-4 Hydroseeding EC-6 Straw Mulch EC-7 Geotextiles and Mats EC-8 Wood Mulching

Contact Information:

Peter Schultze-Allen EOA, Inc. pschultze-allen@eoainc.com 510-847-3548 (cell)

